

06/08/24

PRACTICAL 4

classmate

Date

Page

AIM:

To setup & configure a LAN (Local Area Network) using a switch & ethernet cables in your lab.

LAN (Local Area Network) refers to a network that connect devices within a limited area, such as an office building, school or home. Each connected device on LAN switch can communicate directly with each other, allowing for fast & secure data transfer.

How to set up a LAN:

- ① Plan & design an appropriate network topology taking into account network requirements & location.
- ② You can take 4 computers; a switch with 8, 16, 24 & 4 ethernet cables.
- ③ Connect your computers to network switch via ethernet cable, plugging it into computer.
- ④ Assign IP Address to your PC:
 - ① Login to the client computer as Administrator or as owner.
 - ② Click network & internet connections
 - ③ Right click Local Area connection → Go to properties → Select Internet protocol → click on properties → select use the following IP address option & assign IP address.

Control panel > Network & Internet > Network connections
Networking/ Sharing

IP version 4 (TCP/IPv4) properties

☐ Obtain an IP address automatically

☒ Use the following IP address

IP address

Subnet mask

Default gateway

☒ Use the following DNS server addresses

Preferred DNS server

Alternate DNS server

☐ Validate settings upon exist

Similarly assign IP address to all the PCs connected to switch.

PC1 - IP Address: 10.1.1.1, subnetmask 255.0.0.0

PC2 - IP Address: 10.1.1.2, subnet 255.0.0.0

⑤ Configure a network switch:

1. Connect your computers to a switch:
To access the switch's web interface, you will need to connect your computers to the switch using Ethernet cable.

2. Log in to web interface: Open a web browser & enter the IP address of switch in the address bar.

3. Configure basic settings: once logged in, you will be able to configure basic settings for switch:


4. Assign IP address as 10.1.1.5, subnet mask 255.0.0.0.

Date: _____
Page: _____

⑥ check connectivity between switch & other machine by using ping command in the command prompt of the device.

⑦ Select a folder → go to properties → click sharing tab to share it with everyone on the same LAN

⑧ Try to access shared folder from other computers of network.



RESULT:

To setup & configure a LAN using a switch & ethernet cables.

[Signature]
7/8/14